







Similar to a type 151, it is used to set the upright at an angle between 30° & 45°. This fitting should only be subjected to light loads which cannot be positioned at 90° to the applied load. For greater load use a type 132 and bend the upright.

DESCRIPTION: ANGLE	BASE FLANGE (30	O° TO 45°)

- 1							
		NAME	DATE	REVISION	UNLESS OTHERWISE SPECIFIED		
	DRAWN			Α	ALL DIMENSIONS ARE IN MILLIMETERS		A3
	CHECKED				DO NOT SCALE DRAWING	SCALE:1:1	